

# Adapting the Kenwood Navigation system to the Rockford Fosgate audio system in the Suzuki Kizashi

*IMPORTANT: this guide does not apply to any other  
head-units, systems, or vehicles.*



**The following steps will need to be performed on all sources. Including Tuner AM and FM, DVD, iPod, XM , Sirius and Video.**

1. Press **SRC Select**



2. Select **Tuner**



3. Select the **Arrow button** on the top left of the screen. This will open a tool bar



4. Once the tool bar is open

Select the **tool button** on the far left of the tool bar (Shaped like a wrench)



5. The SETUP Menu will open

Select the **down arrow** on the lower left side of the screen to go to page 2



6. Once on page 2

Select **Audio SETUP**



7. Select **Speaker Select**



8. Press the **arrow** just below the word Front 1 time to change the setting from Standard to **Wide**.



9. Select the **Audio Control button** for the control bar. (shaped like a speaker)



10. This will bring up the **Audio Control Menu**

Select **Audio Control**



11. Set the **Volume Offset to -10** by pressing the down arrow.

12. Once the Volume Offset is set to -10 press the **return arrow** button on the bottom right of the screen.



13. Select the **Equalizer button**

14. Select **Tone Button** lower right corner of the screen.



15. Select the **Bass button**

Using the Up and Down arrows set the  
**FREQ to 50Hz**

**Level to 8**

**Q Factor to 1.00**

**Bass DC EXT ON**



16. Select the **Middle button**

Using the Up and Down arrows set the  
**FREQ to 500Hz**

**Level to 1**

**Q Factor to 1.00**



17. Select the **Treble button**

Using the Up and Down arrows set the  
**FREQ to 17.5kHz**

**Level to 3**

Select **Menu** to go back to **SRC Select**  
screen



**Repeat 1 through 17 on all sources.**  
**Including Tuner AM and Tuner FM,**  
**DVD, iPod, XM ,Sirius and Video.**